

Instructions on how it was trained
Mukhtar Rabayev
Hof University of Applied Sciences

Firstly, collected all photos like that in Jupyter Notebook, after that used Google Collab with faster GPU

```
Ввод [3]: import uuid
import os
import time

Ввод [32]: IMAGES_PATH = os.path.join('YOLO/data', 'images')
labels = ['awake', 'drowsy']
number_imgs = 20

Ввод [33]: cap = cv2.VideoCapture(1)

for label in labels:
    print('Collecting images for {}'.format(label))
    time.sleep(5)

    for img_num in range(number_imgs):
        print('Collecting images for {}, image number {}'.format(label, img_num))

        ret, frame = cap.read()

        imgname = os.path.join(IMAGES_PATH, label+'_'+str(uuid.uuid1())+'.jpg')
        cv2.imwrite(imgname, frame)
        cv2.imshow('Image Collection', frame)
        time.sleep(2)

        if cv2.waitKey(10) & 0xFF == ord('q'):
            break
    cap.release()
    cv2.destroyAllWindows()
    cv2.waitKey(1)
```

Collecting images for awake
Collecting images for awake image number 0

Step 1: Install Ultralytics library
!pip install ultralytics==8.0.196

Step 2: Set the current working directory
import os
HOME = os.getcwd()
print(HOME)

Step 3: Clear output in IPython display
from IPython import display
display.clear_output()

Step 4: Import YOLO module from Ultralytics
from ultralytics import YOLO

Step 5: Load YOLOv8 model and make a prediction
model = YOLO(f'{HOME}/yolov8n.pt')
results =
model.predict(source='https://media.roboflow.com/notebooks/examples/dog.jpeg
', conf=0.25)

Step 6: Change directory and install Roboflow library

```
%cd {HOME}
!pip install roboflow
```

```
# Step 7: Set up Roboflow API and download YOLOv8 dataset
```

```
from roboflow import Roboflow
rf = Roboflow(api_key="rn6ihiuQcsvlnZflUNcO")
project =
rf.workspace("hof-university-of-applied-sciences-5x05r").project("unocards-z8f0f"
)
dataset = project.version(3).download("yolov8")
```

```
# Step 8: Train YOLOv8 model
```

```
%cd {HOME}
!yolo task=detect mode=train model=yolov8s.pt data={dataset.location}/data.yaml
epochs=25 imgsz=640
```

```
# Step 9: Display confusion matrix image
```

```
from IPython.display import Image
image_path = "/content/runs/detect/train/confusion_matrix.png"
Image(filename=image_path, width=600)
```

```
# Step 10: Display results image
```

```
image_path = "/content/runs/detect/train/results.png"
Image(filename=image_path, width=600)
```

```
# Steps 11-13: Additional training, validation, and prediction steps
```

```
image_path = "/content/runs/detect/train/val_batch0_pred.jpg"
Image(filename=image_path, width=600)
```

```
!yolo task=detect mode=val model=/content/runs/detect/train/weights/best.pt
data={dataset.location}/data.yaml
```

```
!yolo task=detect mode=predict
model=/content/runs/detect/train/weights/best.pt conf=0.25
source={dataset.location}/test/images
```

```
# Step 14: Display multiple prediction images
```

```
import glob
from IPython.display import Image, display
for image_path in glob.glob(f'{HOME}/runs/detect/predict/*.jpg')[:-1]:
    display(Image(filename=image_path, width=600))
    print("\n")
```

```
# Steps 15-18: Repeat training, validation, and prediction with different models
```

```
!yolo task=detect mode=predict
model=/content/runs/detect/train2/weights/best.pt conf=0.25
source=/content/IMG_5432.MOV
```

... # Repeat similar steps until train7

%cd {HOME}

**!yolo task=detect mode=train model=/content/runs/detect/train7/weights/best.pt
data={dataset.location}/data.yaml epochs=10 imgsz=640**

**!yolo task=detect mode=val model=/content/runs/detect/train8/weights/best.pt
data={dataset.location}/data.yaml**

**!yolo task=detect mode=predict
model=/content/runs/detect/train8/weights/best.pt conf=0.25
source={dataset.location}/test/images**

Step 19: Display final results image

**image_path = "/content/runs/detect/train8/results.png"
Image(filename=image_path, width=600)**

Step 20: Create a zip file of the content

!zip -r /content/content.zip /content

Step 21: Download the zip file

**from google.colab import files
files.download('/content/content.zip')**